

DISPLAY **A**

Watch hands

Second hand
Hour hand
Minute hand
Date indicator
Setting crown
(Position 0, I, II, III)

SETTING **B**

Setting crown 4 positions

Crown pressed in: >3 sec.
display of month and then the
cycle of the year in window

Normal running of watch

Correcting the timezones

Correcting time position:
hours, minutes and stop-second

GB

ETA Cal. 252.511/611

Eta Swiss Technology

400 985 - 29.03.2004 / ETA / 00

CORRECTIONS **C**

a) Correcting the date

Crown in position II:
the date will change
when hour hand
passes midnight.

Crown pressed in: >3 sec.
display of month during 8 sec.
then cycle of the year during 8 sec.
in window

b) Correcting the month

Crown in position II:
the month will change
when hour hand
passes 12 o'clock.

1 = January
2 = February
. 6 = June
. 12 = December

c) Correcting the cycle of year

Crown in position II:
the year will
change when
hour hand
passes
12 o'clock.

I = Leap year+1
II = Leap year+2
III = Leap year+3
IV = Leap year