




DISPLAY AND CROWN OPERATION




Note:

- | | | | |
|-----------------|------------------------|---------------------------------------|------------------|
| *1: Hour hand | *4: Date calendar hand | *7: Crown at normal position | *9: Second click |
| *2: Minute hand | *5: Day calendar hand | *8: First click | •Time setting |
| *3: Second hand | *6: 24 Hour hand | •Date setting (Quick change function) | |


TIME SETTING




1.Pull out the crown to the second click when the second hand is at the 12 O'clock position.



2.Push the crown back into the normal position in signal.



3.Pull out the crown to the first click. Turn the crown counter-clockwise to set the date.



4.Push the crown back into the normal position.

Turn the crown rotation to set the day of the week.

Turn the crown to set the hour and minute hands to the time.
(Check that AM / PM is set correctly)

*Do not set the date between 10:00 PM and 2:00 AM

Otherwise the day could not change properly. If it is necessary to set the date during that time period, once change the time to any time except the period, and then set the date.

After that set the time correctly.

Notes in time setting of Cal.VH8 series

When time setting is done with counterclockwise, date hand might reverse but there is no problem for the function.

Please set the date by using quick change function when date showing is incorrect.