


DISPLAY AND CROWN / BUTTON OPERATION



^{*}The measurement time indicated by the stopwatch hands that move independently of center hands.

After one minute, it indicates the measurement time when it is stopped.

ADJUSTING THE STOPWATCH HAND POSITION

Before setting the time, check if the stopwatch 1/10 second, second and minute hands are in the "0" (12 o'clock) position.


*If the stopwatch is in use, press the button in the following order to reset it, and then, check if the hands return to "0" position. (For details, see "HOW TO USE THE STOPWATCH")

* If the stopwatch is counting: A → B

* If the stopwatch is stopped: B

* If the split time is displayed : $B \rightarrow A \rightarrow B$

If either of the stopwatch hands are not in the "0" position, reset them following the procedure below.



1.Pull out the crown.

- 2.Press button A or B to reset the stopwatch 1/10 second, second and minute hands to "0" position.
- *By pressing button A set the stopwatch 1/10 second hand.
- *By pressing button B set the stopwatch second and minute hands.
- *The stopwatch minute hand moves correspondingly with the stopwatch second hand.

3. Push the crown back to

the normal position.


^{*}Stopwatch 1/10 second hand moves for a first minute.

^{*}The hands move quickly if the respective buttons are kept pressed.


OPERATION




TIME SETTING



- 1.Pull out the crown to the second hand is at the 12 o'clock position. The second hand will stop on the spot.
- * Do not press any button.
 Otherwise, the chronograph hands will move.



2.Turn the crown to set the hour, minute hands to the desired time. As the hour hand moves, the Sun & Moon disc also moves correspondingly. When setting the hour hand, check that the Sun & Moon disc is set property. (Check that AM / PM is set correctly)



3. Push the crown back in to the normal position in accordance with a time signal.







HOW TO USE THE STOPWATCH

- The measurement time is indicated by the stopwatch hands that move independently of the center hands.
- •The stopwatch can measure up to 60 minutes in 1/10 second.

(Standard measurement)




(Accumulated elapsed time measurement)



^{*}Restart and stop of the stopwatch can be repeated as many times as necessary by pressing button A.

(Split time measurement)



^{*}Measurement and release of the split time can be repeated as many times as necessary by pressing button B.