

**DISPLAY** **A**

Watch hands

Hour hand  
Second hand  
Minute hand  
Date indicator  
Setting crown (Position 0, I, II, III)

**SETTING** **B**

Setting crown 4 positions

Crown pressed in: >3 sec. display of month and then the cycle of the year in window

Normal running of watch

Correcting the timezones

Correcting time position: hours, minutes and stop-second

GB

ETA Cal. 252.511/611

*Eta Swiss Technology*

400 985 - 29.03.2004 / ETA / 00

**CORRECTIONS** **C**

a) Correcting the date

Crown in position II: the date will change when hour hand passes midnight.

Crown pressed in: >3 sec. display of month during 8 sec. then cycle of the year during 8 sec. in window

b) Correcting the month

Crown in position II: the month will change when hour hand passes 12 o'clock.

1 = January  
2 = February  
. = June  
12 = December

c) Correcting the cycle of year

Crown in position II: the year will change when hour hand passes 12 o'clock.

I = Leap year+1  
II = Leap year+2  
III = Leap year+3  
IV = Leap year