









DISPLAY AND CROWN OPERATION



Note:

- | | | | |
|-----------------------|------------------------|---------------------------------------|------------------|
| *1: Hour hand | *4: Date calendar hand | *7: Crown at normal position | *9: Second click |
| *2: Minute hand | *5: Day calendar hand | *8: First click | •Time setting |
| *3: Small second hand | *6: 24 Hour hand | •Date setting (Quick change function) | |


TIME SETTING

1. Pull out the crown to the second click when the small second hand is at the 12 O'clock position.

Turn the crown rotation to set the day of the week.

Turn the crown to set the hour and minute hands to the time.

(Check that AM / PM is set correctly)



2. Push the crown back in to the normal position in signal. Pull out the crown to the first click .



3. Pull out the crown to the first click. turn the crown counter-clockwise to set the date. (Quick change function)





4. Push the crown back in to the normal position.

*Do not set the date between 10:00 PM and 2:00 AM

Otherwise, the day may not change properly. If it is necessary to set the date during that time period, First change the time to any time outside it, set the date and then reset the correct time.


DISPLAY AND CROWN OPERATION




Note:

- *1: Hour hand
- *2: Minute hand
- *3: Small second hand
- *4: 24 Hour hand
- *5: Crown at normal position
- *6: First click
 - Time setting


TIME SETTING



1. pull out the crown to the second click when the small second hand is at the 12 O'clock position.



2. Turn the crown to set the hour and minute hands to the time. (Check that AM / PM is set correctly)



3. Push the crown back in to the normal position in accordance with a time signal.